



W5USJ Drawing 9 May 2016

E B C C B E PN2222 2N3866 2N3906

V1 boards, a mod is needed to add the 22 pF cap to have the crystals close to marked value.

Cut the trace between the crystal and junction

and tack the 22 pF cap to the trace ends..

of 82 pF and 2k2 resistor. Scrape the trace bare