


Another 3 pin section of SIP socket is used for a crystal socket to facilitate changing crystals.

The piece of 4 conductor ribbon cable cable needs to be split into a pair of 2 conductor cables. Then strip and tin all for ends for quick soldering to the stereo jack and the power input connector of your choice or possibly the RF output RCA connector. Clip off the internal switch connections on the stereo jack for easier



attachment to the connectiona that you Do need to use: the tip, ring and ground connections. After checking continuity is good, add some hot glue to the connections for strain relief.



Now you should be ready for a QUICK video build session.....